

# HumminGuru Orbit


## Vinyl Record Static Remover

### Owner's Manual



### Model: HG03

Thank you for purchasing the HumminGuru Orbit Vinyl Record Static Remover. To use this product safely and effectively, please read the manual thoroughly and ensure a clear understanding before operation. After reading, please keep the manual accessible for future reference.



### Safety Precaution

**Important!** Read all instructions carefully before use and keep it for future reference.

HumminGuru Orbit Vinyl Record Static Remover is limited to eliminating statics on vinyl records that are made out of polyvinyl chloride only. This page mainly refers to safety precautions to prevent property damage and danger to users and others. After understanding the indication and the symbols clearly, please read thoroughly and follow the instructions strictly.

**WARNING**  
Indicating "when the product is used wrongly, it may cause severe injuries<sup>\*1</sup> and death."

**CAUTION**  
Indicating "when the product is used wrongly, the user may get injured<sup>\*2</sup> or the product may cause property damage<sup>\*3</sup>."

\*1: Severe injuries mean to get an electric shock, short circuit, and ignition.  
\*2: Getting injured mean you get wound and electric shock.  
\*3: Property damages means the damage to the accommodations, properties, the machine, and vinyl records, etc.

| Symbol Explanation                                                                                                                             |                           |                       |                        |
|------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|-----------------------|------------------------|
|                                                                                                                                                |                           |                       |                        |
| Prohibited                                                                                                                                     | Disassemble is prohibited | Soaking is prohibited | Wet hand is prohibited |
| ⊘ indicates prohibition (must not do). The details of the prohibition will be instructed by sentences or illustration nearby or in the symbol. |                           |                       |                        |
|                                                                                                                                                |                           |                       |                        |
| Mandatory                                                                                                                                      | Unplug                    |                       |                        |
| ! indicates mandatory (must do). The details of the mandatory will be instructed by sentences or illustration nearby or in the symbol.         |                           |                       |                        |

**CAUTION: Charging**

- DO NOT charge the product with a voltage that exceeds the rated specification.

- Avoid charging the product on the surface of flammable objects.
- DO NOT touch or use the product with wet hands.
- In case the product fails to charge, try using a new charging cable.

- If abnormal heat or deformation occurs during charging, immediately stop the charging process.
- If the product will not to be used for an extended period, switch off the power and charge it once every three months.

**WARNING : The Device**

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. The appliance is only to be used with the charging cable provided with the appliance.

- DO NOT use it on anything except the vinyl record.
- DO NOT touch the ion pins and the fan inside during the operation.
- DO NOT move the device during the operation.

- DO NOT disassemble, fix, repair, or modify the device in any way without the authorization of the manufacturer.


- DO NOT expose the device to water or immerse the device in water.
- Always keep the device out of children's reach.

**CAUTION**


- DO NOT leave the device unintended during operation.
- DO NOT turn on the device without the ion air outlet protection lid.
- DO NOT drop the device.

- Clean the fan blades and the ion pins with the provided cleaning brush after use.
- Keep the device on a level surface.

- Switch off the power before proceeding with the product maintenance process.




### Overview



### Charging the Device

Located on the side of the device are four battery indicator lights. When the battery is low, only the bottom light will illuminate. To charge the device, begin by plugging one end of the provided USB-C cable into the charging port and the other end into a power outlet. During charging, the light will flash. Once the device reaches full charge, all four indicator lights will light up.




**Notice:**


- Please use only the provided USB-C charging cable for charging the device.

Using the Device


1. **Powering on the device**  
Slide the power switch located on the back side to the left.




2. **Positioning the device**  
Carefully place the device on top of the turntable with a record on it. Align the spindle hole of the device with the turntable spindle. Ensure that the device does not come into contact with any surrounding objects or parts on top of the turntable platter while operating.



3. **Starting the device**  
Press the start/stop button to initiate the operation mode. The device will rotate for 10 rounds, effectively eliminating static from the vinyl record. After completing the 10 rotations, the device will automatically stop.



4. **Cycle Complete**  
Once the cycle is complete, slide the power switch to the right to turn off the device. Carefully lift and remove it from the turntable spindle in an upward direction.



- Notice:**
- The effectiveness of static removal may vary depending on factors such as the material of the vinyl record, temperature, humidity, and the type of turntable platter, etc.
  - Removing the external air inlet lid will disable the start/stop button.


- **CAUTION**
- Before use, verify that there is unrestricted space on a turntable platter with a minimum diameter of 326 mm for rotation.
  - DO NOT touch the ion pins while the device is in operation mode.
  - DO NOT start the device without the ion air outlet protection lid properly installed.
  - Switch off the power when the device is not in use.

Maintenance


Follow the maintenance process outlined below after each use. Before proceeding, ensure that the device is switched off.

Cleaning the Fan

1. **Remove the external air inlet lid**  
Carefully slide the lid upward with some force.




2. **Clean the fan blades with the brush**  
Use the provided cleaning brush to gently remove visible dust particles from the fan blades. After cleaning, remember to close the external air inlet lid.




Cleaning the Ion Pins

1. **Remove the ion air outlet protection lid**  
Carefully remove the lid by applying some force to one side first, and then to the other side.



2. **Clean the ion pins with the brush**  
Use the provided cleaning brush to gently remove visible dust particles on the ion pins. After cleaning, remember to reinstall the lid.



Specification

|                         |                                                 |
|-------------------------|-------------------------------------------------|
| Product Name:           | HumminGuru Orbit Vinyl Record Static Remover    |
| Model:                  | HG03                                            |
| Input Voltage:          | DC 5V $\equiv$ 1.8A via USB-C                   |
| Max Power Output:       | 4.5 W                                           |
| Battery Capacity:       | 6000mAh                                         |
| Standard Charging Time: | 4 - 5 hours                                     |
| Amount of Ion:          | $\geq (\pm) 50 \times 10^6$ pcs/cm <sup>3</sup> |
| Operation Distance:     | 23mm                                            |
| Product Size:           | 270 x 92 x 104mm                                |
| Product Weight:         | 625g                                            |

- **CAUTION**
- Switch off the power before starting the maintenance process.
  - Keep small accessories away from children.
  - Remember to reinstall all lids before using the device again.

Limited Warranty

HumminGuru warrants this product against defects in material or workmanship for the original owner and any subsequent end user owner(s) ("You" or "Your") for one year from the original date of receipt of the product.

Pursuant to this Limited Warranty, HumminGuru will, at its option, (i) repair the product using new or refurbished parts, or (ii) replace the product with a new or re-certified/refurbished product. In the event of a defect, these are your exclusive remedies. HumminGuru does not warrant that the operation of the product will be uninterrupted or error-free.

This Limited Warranty covers only the HumminGuru Orbit Vinyl Record Static Remover and does not cover separate accessories and technical assistance for hardware usage.

To obtain warranty service, you must contact our customer support (support@happywell.com.hk) and deliver the product, in either its original packaging or packaging affording an equal degree of protection to the designated service location together with a dated purchase receipt to obtain warranty service. HumminGuru cannot guarantee that it will be able to repair any product under this Limited Warranty.

Repair/Replacement Warranty

This Limited Warranty shall apply to any repair, replacement part or replacement, rectified or refurbished product for the remainder of the original Limited Warranty period or for ninety (90) days, whichever is longer.

HumminGuru is not responsible for, and this Limited Warranty does not cover, any damage arising from a failure to operate the product within its intended uses, or otherwise follow the owner's manual and safety instructions relating to the product's use and installation. HumminGuru is not responsible for any labor or parts costs you incur relating to repairs or services from providers/servicers other than from HumminGuru authorized providers/servicers. This Limited Warranty only covers product issues caused by defects in material or workmanship during ordinary consumer use. This Limited Warranty is non-transferable. No other warranty, written or oral, is authorized by HumminGuru.

This Limited Warranty does not cover products purchased from sources other than HumminGuru or HumminGuru authorized dealer (including non-authorized online auctions), or issues due to: (i.) Outdoor exposure and other acts of nature;

(ii.) Power surges; (iii.) Lack of reasonable care; (iv.) Accidental damage; (v.) Misuse or abuse; (vi.) The affixing or any attachment not provided with the product; (vii.) Damage, malfunction and/or failure to product resulting from use of parts or supplies not sold or authorized by HumminGuru; (viii.) Damage; malfunction and/or failure to product resulting from servicing not authorized or performed by HumminGuru; (ix.) Modifications of or to any of the product; (x.) Shipping damage; (xi.) Loss of part.

LIMITATION ON DAMAGES:

**HUMMINGURU SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES DUE TO A DEFECTIVE PRODUCT OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION ON THIS PRODUCT.**

The product must be shipped postage prepaid to HumminGuru's designated service location. Damage occurring during shipment is not covered by this Limited Warranty. Shipping costs are non-refundable.

**Model: HG03**  
HumminGuru Orbit  
Vinyl Record Static Remover

Purchase Date: (dd/mm/yy)

Purchase Order #:

Find out more at  
[www.humminguru.com](http://www.humminguru.com)

Contact

For replacement parts, service, or questions, please contact customer support. Email: support@happywell.com.hk

Happy Well International Enterprise Limited

Rm. 1202, 12/F New Mandarin Plaza, Tower B,  
No.14 Science Museum Road,  
Tsim Sha Tsui East,  
Kowloon, Hong Kong

HG03OM00010EN

Printed in China